Bump Test Log

| Bring your H ₂ S monitor to bump test | \Rightarrow | Connect monitor to tubing and gas. Then follow instructions. | \Rightarrow | Check if all alarms work and if concentration shows 25 ppm | \Rightarrow | Record type of monitor and if it passed |
|--|---------------|---|---------------|---|---------------|---|
|--|---------------|---|---------------|---|---------------|---|

| bump test | moti detions. | 3110W3 23 pp111 | | |
|-----------|---------------|-------------------|--|--|
| | Monitor Type | Passed Bump Test? | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | • | | |

Checklist and Order Form 1